

Table A-1. Compass Keyboard Codes

Key	Unshifted	SHIFT	CODE	CODE-SHIFT	CTRL	SHIFT-CTRL	CODE-CTRL	CODE-SHIFT-CTRL
'	27 (')	22 (*)	60 (')	5C (\)	07 (BEL)	02 (STX)	00 (NUL)	1C (FS)
,	2C (,)	3C (<)	5B (C)	7B (C)	0C (FF)	1C (FS)	1B (ESC)	1B (ESC)
-	2D (-)	5F (_)	AD	7F DEL	0D (CR)	1F (US)	8D	1F (US)
.	2E (.)	3E (>)	5D (J)	7D (J)	0E (SO)	1E (RS)	1D (GS)	1D (GS)
/	2F (/)	3F (?)	BF	BF	0F (SI)	1F (US)	9F	9F
0	30 (0)	29 (I)	B0	A9	10 (DLE)	09 (HT)	90	89
1	31 (1)	21 (!)	B1	A1	11 (DC1)	01 (SOH)	91	81
2	32 (2)	40 (@)	B2	C0	12 (DC2)	00 (NUL)	92	80
3	33 (3)	23 (#)	B3	A3	13 (DC3)	03 (ETX)	93	83
4	34 (4)	24 (\$)	B4	A4	14 (DC4)	04 (EOT)	94	84
5	35 (5)	25 (%)	B4	A5	15 (NAK)	05 (ENQ)	95	85
6	36 (6)	5E (^)	B6	DE	16 (SYN)	1E (RS)	96	9E
7	37 (7)	26 (&)	B7	A6	17 (ETB)	06 (ACK)	97	86
8	38 (8)	2A (*)	B8	AA	18 (CAN)	0A (LF)	98	8A
9	39 (9)	28 (())	B9	A8	19 (EM)	08 (BS)	99	88
;	3B (;)	3A (:)	7E (~)	7C (!)	1B (ESC)	1A (SUB)	1E (RS)	1C (FS)
=	3D (=)	2B (+)	BD	AB	1D (GS)	0B (VT)	9D	8B
A	61 (a)	41 (A)	E1	E1	01 (SOH)	01 (SOH)	81	81
B	62 (b)	42 (B)	E2	E2	02 (STX)	02 (STX)	82	82
C	63 (c)	43 (C)	E3	E3	03 (ETX)	03 (ETX)	83	83
D	64 (d)	44 (D)	E4	E4	04 (EOT)	04 (EOT)	84	84
E	65 (e)	45 (E)	E5	E5	05 (ENQ)	05 (ENQ)	85	85
F	66 (f)	46 (F)	E6	E6	06 (ACK)	06 (ACK)	86	86
G	67 (g)	47 (G)	E7	E7	07 (BEL)	07 (BEL)	87	87
H	68 (h)	48 (H)	E8	E8	08 (BS)	08 (BS)	88	88
I	69 (i)	49 (I)	E9	E9	09 (HT)	09 (HT)	89	89
J	6A (j)	4A (J)	EA	EA	0A (LF)	0A (LF)	8A	8A
K	6B (k)	4B (K)	EB	EB	0B (VT)	0B (VT)	8B	8B
L	6C (l)	4C (L)	EC	EC	0C (FF)	0C (FF)	8C	8C
M	6D (m)	4D (M)	ED	ED	0D (CR)	0D (CR)	8D	8D
N	6E (n)	4E (N)	EE	EE	0E (SO)	0E (SO)	8E	8E
O	6F (o)	4F (O)	EF	EF	0F (SI)	0F (SI)	8F	8F
P	70 (p)	50 (P)	F0	F0	10 (DLE)	10 (DLE)	90	90
Q	71 (q)	51 (Q)	F1	F1	11 (DC1)	11 (DC1)	91	91
R	72 (r)	52 (R)	F2	F2	12 (DC2)	12 (DC2)	92	92
S	73 (s)	53 (S)	F3	F3	13 (DC3)	13 (DC3)	93	93
T	74 (t)	54 (T)	F4	F4	14 (DC4)	14 (DC4)	94	94
U	75 (u)	55 (U)	F5	F5	15 (NAK)	15 (NAK)	95	95
V	76 (v)	56 (V)	F6	F6	16 (SYN)	16 (SYN)	96	96
W	77 (w)	57 (W)	F7	F7	17 (ETB)	17 (ETB)	97	97
X	78 (x)	58 (X)	F8	F8	18 (CAN)	18 (CAN)	98	98
Y	79 (y)	59 (Y)	F9	F9	19 (EM)	19 (EM)	99	99
Z	7A (z)	5A (Z)	FA	FA	1A (SUB)	1A (SUB)	9A	9A
BACKSPACE	08	C8	88	8A	08 (BS)	88	88	8A
RETURN	0D	CD	8D	8C	0D (CR)	8D	8D	8C
DownArrow	C4	CE	D2	D6	84	BE	92	96
ESC	1B	1B	9B	9B	1B (ESC)	1B (ESC)	9B	9B
LeftArrow	C6	D0	D4	D8	86	90	94	98
RightArrow	C7	D1	D5	D9	87	91	95	99
Spacebar	20 (SP)	20 (SP)	20 (SP)	20 (SP)	00 (NUL)	00 (NUL)	00 (NUL)	00 (NUL)
TAB	09	C9	89	8B	09	89	89	8B
UpArrow	C5	CF	D3	D7	85	BF	93	97