

COMMON COMMANDS

CHDIR	Changes directories (CD)
CHKDSK	Checks disk directory
CLS	Clears screen
COPY	Copies file(s)
DATE	Displays current date
DEL	Deletes file(s) (ERASE)
DIR	Lists directory entries
DISKCOPY	Copies entire disks
DEVICES	Lists active devices
FDISK	Partitions a hard disk
FORMAT	Initializes a disk

MKDIR	Makes a directory (MD)
PRINT	Print text file(s)
RECOVER	Recovers a bad disk
REN	Renames a file (RENAME)
RMDIR	Removes a directory (RD)
SETTIME	Sets time and date
SYS	Transfers system files
TIME	Displays current time
TYPE	Displays file contents
VER	Prints MS-DOS version number
VOL	Prints volume identification

OTHER COMMANDS

BREAK	Sets CTRL-C check
CTTY	Changes console TTY
EXE2BIN	Converts .EXE files to .BIN
EXIT	Exits command processor
FIND	Searches for text
MORE	Displays 1 screen at a time
PATH	Sets a command search path
PROMPT	Designates command prompt
SET	Sets string1=string2
SORT	Sorts data alphabetically
VERIFY	Verifies writes to disk

BATCH COMMANDS

ECHO	Displays batch commands
FOR	Conditional control
GOTO	Branch control
IF	Conditional control
PAUSE	Pauses for input
REM	Displays a comment
SHIFT	Batch parameters access

GRID

MS-DOS COMMANDS

Version A ©1983

COMMON COMMANDS

CHDIR	DEL	FORMAT	RMDIR	VER
CHKDSK	DIR	MKDIR	SETTIME	VOL
CLS	DISKCOPY	PRINT	SYS	
COPY	DEVICES	RECOVER	TIME	
DATE	FDISK	REN	TYPE	

OTHER COMMANDS

BREAK	PATH
CTTY	PROMPT
EXE2BIN	SET
EXIT	SORT
FIND	VERIFY
MORE	

BATCH COMMANDS

ECHO	REM
FOR	SHIFT
GOTO	
IF	
PAUSE	

KEYBOARD CHARACTERS

[CODE ,]	[
[CODE .]]
[CODE SHIFT ,]	{
[CODE SHIFT .]	}
[CODE ;]	~
[CODE SHIFT ;]	
[CODE ']	'
[CODE SHIFT ']	\
[SHIFT ESC]	CAPS LOCK

MS-DOS FUNCTION KEYS Press **CODE** - **SHIFT** - for first row. Press **CODE** - for second row.

F11

F12

F13

F14

F15

F16

F17

F18

F19

F20

F1

F2

F3

F4

F5

F6

F7

F8

F9

F10

DEL

INS